

**VERY IMPORTANT**

**HYDRAULIC SYSTEM LIQUID**

This liquid (GREEN in color) has a MINERAL base (similar to engine oil) and is COMPLETELY DIFFERENT FROM ANY OTHER LIQUID USED TO DATE.

The level of the liquid in the reservoir, situated next to the radiator, should be between the MINI and MAXI marks on the transparent gauge of the reservoir.

If it is necessary to replenish the liquid, USE ONLY THE GREEN FLUIDS, sold in GREEN cans bearing the letters LHM in GREEN. This liquid is supplied by any CITROEN Dealer. ALL OTHER LIQUIDS ARE HARMFUL, particularly those with a SYNTHETIC or VEGETABLE BASE such as LHS2 and ALL BRAKE FLUIDS which would quickly and completely destroy the hydraulic system of your car.

In an emergency, you may use an oil similar to that used in the converters of automatic transmissions (Fluid A Type A), but in such a case have the reservoir drained and replenished with the recommended liquid as soon as possible.

# INDEX

	Page		Page
<b>IMPORTANT REFERENCES</b>			
• Addresses, Offices, Service and Parts .....	3	• Shifting Hydraulic Shift (DX-DXF) .....	27
• Consumer Information (Federal Safety Standards—Regulation 375)	} See Inserted Folder	• Starting on a Hill (DX-DXF) .....	28
—Tire Reserve Load (Std.-C-102)		• Stopping with Hydraulic Shift (DX-DXF) .....	28
—Acceleration on Passing Ability (Std.-C-106)		• Parking with Hydraulic Shift (DX-DXF) .....	28
—Vehicle Stopping Distance (Std.-C-101)		• To Start with Crank Handle .....	29
• Hydraulic Fluid .....	21	• Anti-Theft Lock with Ignition Contact and Starter Switch (DJ-DJF-DV) .....	30
• Identification Plates and Labels .....	8	• Starting with Mechanical Shift (DJ-DJF-DV) .....	32
• Major Specifications and Settings .....	10 & 11	• Shifting — Mechanical Shift (DJ-DJF-DV) .....	33
• 600 Mile Inspection .....	12	• Recommended Speeds .....	33
• Break-In Period .....	13	• Service Brake .....	34
• Air Conditioner (Optional) .....	13	• Emergency — Parking Brake (DX-DXF) .....	34
		• Emergency — Parking Brake (DJ-DJF-DV) .....	35
		• Brake Security Control .....	36
		• Distances Required to Stop a Car .....	38 & 39
		• Dashboard (DX-DXF) .....	40 to 48
		• Dashboard (DJ-DJF-DV) .....	49 to 52
		• Road Clearance .....	53
		• Changing a Wheel — Power Jacking .....	55 to 59
<b>DRIVING</b>			
• To Open the Doors .....	16	<b>LUBRICATION AND MAINTENANCE</b>	
• To Open the Tail Gates (DXF-DJF) .....	16	• Maintenance Booklet .....	61
• To Open the Hood .....	18	• Exhaust Emission Control .....	62
• Checking Engine Oil .....	18	• Lubrication Chart .....	64 & 65
• Checking Water Level .....	20	• Maintenance — Additional Operations .....	66
• Checking Hydraulic Fluid Level .....	21	• Engine Lubrication .....	67
• To Drain and Refill Hydraulic Fluid .....	22	• Engine Oil Filter Replacement .....	67
• Keys .....	23	• Gear Box Lubrication .....	67
• Anti-Theft Lock with Ignition Contact (DX-DXF) .....	23		
• Starting with Hydraulic Shift (DX-DXF) .....	25		

## INDEX

	Page		Page
• Brakes .....	68	• Rear Seats (DXF-DJF) .....	85
• Carburetor .....	68	• Seat Belts .....	86
• Filters .....	68	• Sun Visors .....	87
• Fuse Box .....	69	• Rear View Mirror .....	87
• Head Light Adjustment .....	69	• Trunk Light (DX-DJ-DV) .....	87
• Trailer Hitch .....	70	• Luggage Rack (DXF-DJF) .....	87
• Tool Kit .....	70	• Ash Trays .....	87
• Accessory Terminal .....	70	• Thermal Rear Windshield (DX-DJ-DV) .....	87
• Door Windows .....	71	• Ventilation .....	88 & 89
• Air Horns .....	71	• Heating .....	90
• Cooling System Care .....	71	• Defrosting .....	90
• Winterizing .....	71		
• Draining the Cooling System .....	72		
• Radiator Cleaning .....	72		
• Windshield Washers .....	73		
• Cleaning the Car .....	73		
• Battery .....	74		
• Water Pump .....	75		
• Tires .....	75 & 76		
• Towing the Car .....	77		
• Loading the Car on Trailer, on Ship .....	78		
• Tourist Information .....	79		
<b>FEATURES AND COMFORT</b>		<b>GENERAL HINTS AND MINOR TROUBLE SHOOTING</b>	
• Carpets .....	83	• To Clean Hydraulic Filter .....	94
• Front Seats .....	83	• To Bleed Hydraulic Pressure System .....	94
• Front Seat Height Adjustment .....	84	• To Raise the Car with a Floor Jack .....	95
		• To Service Rear Suspension Cylinder Ball .....	95
		• To Start the Engine with Starter Relay .....	95
		• To Replace Spark Plugs .....	96
		• To Replace Oil Filter .....	97
		• To Check Fuel Delivery .....	97
		• To Clean Carburetor Jets .....	98 & 99
		• Hard Starting — To Check the Ignition System .....	100 & 101
		• Alternator — Precautions .....	101 & 102
		• Front End Adjustments .....	102

